

4.4.6 Step Button

- The **Step** area in the **Exposure** mode is provided as two types – **Image** type and **Button** type.
- Click **F8** shortcut in the **Exposure** mode or change settings in the **Setting** mode to switch each type in real time.

Image Type	Button Type
	

4.4.7 Pre-defined Text Button




- The user-defined text buttons are supported which are the pre-defined ones used frequently.
- Refer to Tool Group in VXvue Service Manual for the detailed information about setting **Pre-defined Text**.

4.5 Auto Rotation of UI

- The user interface of **VXvue** is rotated automatically when the screen resolution of a device such as a tablet is changed by rotating it.
- If the vertical resolution is bigger than the horizontal one when you rotate a device, its screen is changed as a vertical layout automatically.

4.5.1 Vertical Layout

VXvue provides a vertical layout when vertical resolution of the screen is bigger than horizontal resolution.



- Vertical Layout is applied normally when horizontal resolution of the screen is more than 1080.