



CUADRO DE COORDENADAS PRIMERA PLANTA		
Puntos	NORTES	ESTES
1	1024290.695	1148231.262
2	1024289.862	1148236.091
3	1024287.024	1148235.495
4	1024284.640	1148235.157
5	1024284.576	1148233.432
6	1024283.933	1148231.881
7	1024283.808	1148230.566
8	1024284.890	1148230.366
9	1024285.019	1148231.781

CUADRO DE COORDENADAS SEGUNDA PLANTA		
Puntos	NORTES	ESTES
1	1024290.695	1148231.262
2	1024289.862	1148236.091
3	1024287.023	1148235.495
4	1024284.050	1148235.074
5	1024282.887	1148235.078
6	1024282.877	1148232.583
7	1024281.072	1148230.313
8	1024283.808	1148230.566
9	1024283.933	1148231.881

CUADRO DE COORDENADAS TERCERA PLANTA		
Puntos	NORTES	ESTES
1	1024290.695	1148231.262
2	1024289.862	1148236.091
3	1024287.023	1148235.495
4	1024284.050	1148235.074
5	1024282.887	1148235.078
6	1024282.877	1148232.583
7	1024281.072	1148230.313
8	1024283.808	1148230.566
9	1024283.933	1148231.881
10	1024291.786	1148231.121
11	1024290.953	1148235.949

CUADRO DE ÁREAS	
PRIMERA PLANTA =	25.05 m2

CUADRO DE ÁREAS	
SEGUNDA PLANTA =	31.79 m2

CUADRO DE ÁREAS	
TERCERA PLANTA =	31.79 m2
BALCÓN =	05.15 m2

